


Thermistor


GPL v3

Winder
Power



Puller motor


LCD Info Screen




- ① Actual Extruder barrel temp in deg C
 - ② Setpoint Extruder barrel temp in deg C
 - ③ RPM of the Puller motor
 - ④ RPM of the Extruder motor (also displays 'CO' for cold extruder and 'OF' when external extruder switch is off)
 - ⑤ Measured diameter of filament in mm
 - ⑥ Filament Feed rate at Puller in mm/sec
 - ⑦ Length of filament produced in mm
 - ⑧ Average measured filament diameter
 - ⑨ Minimum measured filament diameter
 - ⑩ Maximum measured filament diameter
- Last row – status or warning message

LCD Menus

While stopped



While running



Menu Explanations 1

Main Menu – While motors are Idle

Info Screen – Returns to the info screen.

Resume extruder – Will turn on the Puller motor, extruder motor (if warmed up), Winder motor, and fan (if warmed up)

Clear Statistics – Clears the Filament average, minimum, maximum, and length.

Enable Statistics – turns on gathering of statistics while extruder is not running.

Prepare – Go to the Prepare menu. Used to get ready for the run.

Preheat ABS – Turn on the heater to the setting for ABS. System will beep when at temperature. Can press the knob to stop the beep.

Cooldown – Turn off the heater

Control – Go to the Control menu, which is used to set parameters for motion, temperature, and filament control.

Main Menu – While motors are running

Info Screen – Returns to the info screen.

Extruder Auto Con – Turns on the PID loop that controls the puller motor speed to hold filament diameter to a fixed setting.

Pause extruder – Turns off all motors.

Clear Statistics – Restarts collection of statistics, including zeroing of extruded length.

Pause Statistics – Pauses collection of statistics, but keeps info in memory.

Tune – Goes to menu used to tune settings such as motor speeds during extrusion

Preheat ABS - Turn on the heater to the setting for ABS. System will beep when at temperature. Can press the knob to stop the beep.

Cooldown – Turns off the heater to allow extruder to cool.

Control– Go to the Control menu, which is used to set parameters for motion, temperature, and filament control.

Prepare Menu

Main – Returns to the Main Menu

Extruder RPM: - Enter the desired extruder RPM. Default is 12.

Puller mm/s: - Enter the desired default puller mm/second. Default is 6 mm/sec

Fil Dia: - Enter the desired filament diameter when using filament PID control. Default is 2.8mm

Winder speed: - Enter the desired winder speed (0-255). Default is 128.

Preheat ABS - Turn on the heater to the setting for ABS. System will beep when at temperature. Can press the knob to stop the beep.

Move axis – Goes to the menu allowing user to move the extruder or puller a set distance.

Menu Explanations 2

Tune Menu

Main – Returns to the Main Menu

Extruder RPM:- Enter the desired extruder RPM. Default is 12.

Puller mm/s:- Enter the desired default puller mm/second. Default is 6 mm/sec

Extruder T:- Enter the desired extruder temperature in deg C. Default is 185 deg.

Fil Dia:- Enter the desired filament diameter when using filament PID control. Default is 2.8mm

Winder speed:- Enter the desired winder speed (0-255). Default is 128.

Move axis Menu

Prepare – Returns to the Prepare Menu

Move 10mm – Will move an axis (extruder or puller) in 10 unit increments

Move 1mm – Will move an axis (extruder or puller) in 1 unit increments

Move 0.1mm – Will move an axis (extruder or puller) in 0.1 unit increments

Select Move Menu

Move axis – Returns to the Move axis Menu

Extruder – Select extruder to move. There are 100 units in one revolution.

Puller – Select the puller motor to move. The units are mm.

Menu Explanations 3

Control Menu

Main – Return the Main Menu

Temperature – Select the Temperature control menu (Heater settings)

Motion – Select the Motion control menu (Motor settings)

Filament PID – Select the Filament PID control menu (Filament PID settings)

Store Memory – Save settings in EEPROM

Load Memory – Load EEPROM settings

Restore failsafe – Go back to default settings

Temperature Menu

Control – Return back to the Control Menu

Extruder T: - Enter the desired extruder temperature in deg C. Default is 185 deg.

PID-P: - Enter the desired P value for the heater PID loop. Default is 12.66. Can use Autotune to tune this just like Marlin.

PID-I: - Enter the desired I value for the heater PID loop. Default is 0.27. Can use Autotune to tune this just like Marlin.

PID-D: - Enter the desired D value for the heater PID loop. Default is 146.24. Can use Autotune to tune this just like Marlin.

PID-C: - Enter the desired C value for the heater PID loop. Default is 1. This is usually not adjusted.

Preheat ABS conf – Menu to configure settings for the standard ABS preheat.

Motion Menu

Control– Return back to the Control Menu

Winder speed:- Enter the desired winder speed (0-255). Default is 128.

Steps/rev: Enter the number of steps per 1/100th of a revolution of the extruder, taking into account the gearbox and fractional steps. Default is 489.6. for stepper with 15.3:1 gears.

Psteps/mm: Enter the number of steps per 1mm of motion of the puller motor, taking into account the gearbox and fractional steps. Default is 2653.6 for stepper with 100:1 gears.

Motor Acc: Enter the acceleration for the steppers in mm/sec². Default is 200.

Ve-jerk: Default is 1.0.

Vmax e: Default is 40 1/100ths revolutions per second, or 24RPM.

Filament PID Menu

Control– Return back to the Control Menu

Fil Dia: - Enter the desired filament diameter when using filament PID control. Default is 2.8mm

PID-P: - Enter the desired P value for the filament diameter PID loop. Default is 0.020.

PID-I: - Enter the desired I value for the filament diameter PID loop. Default is 0.060.

PID-D:- Enter the desired D value for the filament diameter PID loop. Default is 0.250.

Preheat ABS conf Menu

Temperature

Extruder T: - Enter the desired extruder temperature in deg C that will be used when 'Preheat ABS' is selected in the Main Menu or Prepare Menu . Default is 185 deg.

Store memory – Save the settings in EEPROM

Configuring the stepping units

- Extruder

200 steps/rev motor, 15.3:1 reduction gearbox

Jumpers set for 1/16 stepping.

$E_{\text{steps/rev}} = 200 \text{ steps/rev} * 15.3 * 16 * 1/100$

$E_{\text{steps/rev}} = 489.6$

- Puller motor

200 steps/rev motor, 99 1044/2057 : 1 reduction

Urethane wheel is 120 mm circumference

Jumpers set for 1/16 stepping.

$P_{\text{steps/mm}} = 200 \text{ steps/rev} * 99 \text{ 1044/2057} * 16 / 120$

$P_{\text{steps/mm}} = 2653.6$

Using the Extruder

1. Turn on the heater – select Preheat ABS from the Main Menu.
2. Wait until temp hits setpoint (185 deg). Beeper will go. Can press knob to shut off.
3. Turn on the motors – select Resume Extruder from the Main Menu.
4. Adjust the Puller motor speed via the knob to achieve close to the filament diameter desired (2.8mm). Can use the Tune menu or Control menu to make adjustments to motor speeds, etc.
5. Switch to Extruder Auto Con from the Main Menu to go to automatic control of the puller motor.
6. Can Clear Statistics on the Main Menu to start collecting data now that filament is under control.
7. Select Pause Extruder on the Main Menu when finished with run.
8. Select Cooldown on the Main Menu to shut off heater.